


## Quick Start Guide



**kworld®**

**kworld®**

**kworld®**

Without any prior written authorization from KWorld Computer Co., Ltd., any part of this publication may not be reproduced, transcribed, transmitted, and translated in any forms or languages. When the following content contradict to the local laws and decrees, then it does not apply to that particular country.  
KWorld Computer Co., Ltd. is not liable to any errors or inaccuracies that may appear in this booklet. KWorld Computer Co., Ltd. reserves the right to change the content without notice and is under no liability for any implied commitment to warranties of merchantability, quality, or fitness for any particular purpose.

© 2009 KWorld Computer Co., Ltd. All rights reserved. All KWorld trademarks and logos are registered trademark of KWorld Computer Co., Ltd. All other trademarks and logos presented in this material are the property of their respective owner. KWorld Computer Co. Ltd. reserves the right to revise the specifications mentioned on this packaging.

**kworld®**

### I. Package Contents

- USB DMB-TH TV Stick Pro (Model No# UB388-M)
- DMB-TH Antenna
- Quick Installation Guide
- Installation CD
- Remote Control
- USB Cable
- PD7 PP5 CyberLink Combo CD

### II. System Requirements

- CPU :
  - View in SDTV
  - Intel Pentium Mobile 1.8GHz or above or AMD equivalent CPU
  - Intel Pentium 4 2.4GHz (HT) or above or AMD equivalent CPU
- Record or time shift in MPEG-2 format :
  - Intel Pentium Mobile 2.0GHz or above AMD equivalent CPU
  - Intel Pentium 4 Dual-Core 1.6GHz or above or AMD equivalent CPU
- View in HDTV (H.264) :
  - Intel Core 2 Duo Mobile T7100 1.8GHz or above or AMD equivalent CPU
  - Intel Core 2 Duo 1.8 GHz or above or AMD equivalent CPU
- Record in HDTV (H.264) format :
  - Intel Core 2 Duo Mobile T7250 2.0GHz or above or AMD equivalent CPU
  - Intel Core 2 Duo E4500 2.2GHz or above or AMD equivalent CPU
- Graphic Card :
  - SDTV : 64MB or above in memory and supports DirectX 9.0c
  - HDTV : 128MB or above in memory and supports DirectX 9.0c and DXVA
  - \* nVIDIA Geforce 7300GT or above recommended
  - ATI 2600 Pro video card or above recommended
- RAM : 512 MB or above ( 1G is recommended)
- USB Port : Must be an USB 2.0 standard
- Sound card : AC97 compatible and supports Microsoft DirectX 9
- Operating System : Microsoft Windows XP SP3 ` Vista 32-bit SP1 ` Vista 64-bit SP1

### III. Hardware & Software Installation

1. Please plug the cable converter with the antenna into the connecting point of USB DMB-TH TV Stick Pro (KW- UB388-M) for digital reception.
2. Connect the USB DMB-TH TV Stick Pro (KW- UB388-M) to your PC or Notebook via any of the available USB2.0 port.

### IV. Software Installation

1. Once you have properly installed the USB TV stick, the "Found New Hardware Wizard" dialog box will appear. Please click "Cancel" and have your KWorld Installation CD ready for easier and faster installation.
2. Please wait for the installation main screen to appear after you insert the installation CD into your CD-ROM.
3. The installation main screen will appear. It is recommended to choose "Multimedia software and driver". For advanced users, they can go to "Utility" to install the software and program individually.  
**Attention: Advanced users who wish to install the software and program must install "Microsoft.Net Framework" first in order to install TiVme.**
4. You will see a list of installation options at the left side of the window. It is recommended to click "Quick Installation". "Quick Installation" will install all the necessary programs and software for you. You can also install TiVme, driver program or the remote utility individually up to your demand.
5. Please read the "End User License Agreement" and click "Agree".
6. You can choose "Typical Installation" or "Custom Installation". "Typical Installation" will install all the necessary driver, TiVme software and remote utility. You can also choose "Custom Installation" to install the program or software individually. Click "Next" when you made your selection.
7. Please choose the remote control according to the one provided by the product you purchased. Click "Install" after you choose the remote.
8. The installation will take a moment. Please wait.
9. When the installation is complete, the system will ask you whether you would like to restart your computer. Please click "Yes, I want to restart my computer now" to ensure the installation is totally completed.

### V. Running TiVme for the first time

When you activate TiVme for the first time, the system will guide you through the necessary steps of channel scanning.



1. Please select the device type (e.g. digital, analog or hybrid) you purchased and click "Next".
2. Select the signal source (may vary depending on the product you purchased and the area you live), and click "Next".
3. Please select the country you live and then click "Channel Scan."
4. Click "Exit" to finish the setup after the scanning is completed.